

Remove hard top,  
refer to 54 21 001.

Carefully detach bonding points (1).  
Pull off rubber seal (2) towards rear.

**Installation:**

Use profile rubber adhesive (sourcing reference: BMW  
Parts Service) for bonding.

