



- | | | | |
|---|--|---|----------------------------------|
| A | Front impact absorber support, without attached front trim panel | C | Vehicle jack front take-up point |
| B | Front spring support | O | Front axle, mount, front |
| | | P | Front axle mount, center |

Dimensions in mm

Tolerance: dimension over 1000 mm \pm 2.0 mm

Tolerance: dimension up to 1000 mm \pm 1.0 mm

Note:

Only use the indicated values for a rough inspection.

Repairs can only be carried out correctly with the approved set of attachments and with straightening bench.