

12 41 Starter and Mounting Parts

	Type	Thread	Tightening specification	Measure
1AZ Starter motor mounting to transmission bell housing	All			45 Nm
2AZ Support to starter	All	M5		5 Nm
3AZ Support to crankcase	All			47 Nm
4AZ Electrical leads to starter				
	All	M5		5 Nm
	All	M6		7 Nm
	All	M8		13 Nm
5AZ Bolt connection, pole tube	All	M6		6 Nm
6AZ Heat shield to starter motor		M6		6 Nm